OEL Recommended Spare Parts List

OKIFAX 5680

Revision 5

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environmen
					per *	per *	per *			
CABINET ASSEMBLY	1	1PA4120-1079G001	DOCUMENT HOPPER ASSEMBLY	1	*	*	*			G
CABINET ASSEMBLY	2	2PP4120-1084P001	SUB-HOPPER PLATE	1	*	*	*			
CABINET ASSEMBLY	3	41271001	Cover-NCU	1	*	*	*			
CABINET ASSEMBLY	4	1PP4120-1089P001	MAIN COVER	1	*	*	*			
CABINET ASSEMBLY	5	2PA4083-6130G001	MANUAL FEED GUIDE ASSEMBLY	1	*	*	*			
CABINET ASSEMBLY	6e	42310701	Board- EN2	1	*	*	*	OEL		G
CABINET ASSEMBLY	8	3PP4120-1088P001	PARTITION PLATE	1	*	*	*			G
CABINET ASSEMBLY	9	1PP4120-1090P001	REAR COVER	1	*	*	*			
CABINET ASSEMBLY	10	1PP4120-1093P001	STACKER COVER-FD	1	*	*	*			
CABINET ASSEMBLY	15	41632001	Film-Assist	3	*	*	*			
OEP PANEL ASSEMBLY	1a	41260806	Cover Assy.-OP Panel(ODA)	1	*	*	*	ODA/INT/AUS		G
OEP PANEL ASSEMBLY	1b	41260807	Cover Assy.-OP Panel(OEL)	1	*	*	*	OEL/NO-EC,Note 1		G
OEP PANEL ASSEMBLY	2	41261401	Film-Onetouch	2	*	*	*	Note 2		
OEP PANEL ASSEMBLY	3	41261307	Sheet-Onetouch	1	*	*	*			
OEP PANEL ASSEMBLY	4	41261206	Film-Function	1	*	*	*			
OEP PANEL ASSEMBLY	5	4PB4014-4776P211	TEN KEY LABEL	1	*	*	*			
OEP PANEL ASSEMBLY	6	41261306	Sheet-Onetouch	1	*	*	*			
OEP PANEL ASSEMBLY	7	41261001	Cover-Onetouch	1	*	*	*			
OEP PANEL ASSEMBLY	8	43415501	Board-P6F	1	*	*	*			
OEP PANEL ASSEMBLY	9	40732601	Button-Start	1	*	*	*	OKI		
OEP PANEL ASSEMBLY	10	40732701	Button-Stop	1	*	*	*	OKI		
OEP PANEL ASSEMBLY	11	40732804	Button-TenKey	1	*	*	*			
PRINTER ASSEMBLY	1	2PA4120-1214G001	STACKER COVER ASSEMBLY	1	*	*	*			
PRINTER ASSEMBLY	2	4PB3517-1567P001	GUIDE WIRE	1	*	*	*			
PRINTER ASSEMBLY	3	4YB4120-1117P001	PULSE MOTOR(MAIN)-151/175	1	*	*	*			G
PRINTER ASSEMBLY	4	4YB4120-1118P001	PULSE MOTOR(RESIST)-151/175	1	*	*	*			G
PRINTER ASSEMBLY	5	4PP4083-2593P001	IDLE GEAR A	2	*	*	*			
PRINTER ASSEMBLY	6	3PP4083-6076P001	REDUCTION GEAR	1	*	*	*			
PRINTER ASSEMBLY	8b	2YX4120-1128G002	FUSING UNIT ASSEMBLY(230V)	1	*	*	*	Except ODA		G
PRINTER ASSEMBLY	9	3PA4122-1295G001	Hopping Roller Assy	1	*	*	*			
PRINTER ASSEMBLY	10	4PP4083-6022P002	BEARING A	4	*	*	*			
PRINTER ASSEMBLY	11	4PP4083-6086G001	TONER SENSOR ASSEMBLY	1	*	*	*			G
PRINTER ASSEMBLY	12	4PP4083-6083P001	SENSOR PLATE(IN)	3	*	*	*			
PRINTER ASSEMBLY	13	4PB4083-6024P001	ONE-WAY CLUTCH GEAR	2	*	*	*			G
PRINTER ASSEMBLY	14	4PP4083-6080P001	IDLE GEAR B	1	*	*	*			
PRINTER ASSEMBLY	15	3PP4083-6054P001	RESET LEVER R	1	*	*	*			
PRINTER ASSEMBLY	16	4PP4083-6081P001	IDLE GEAR C	1	*	*	*			
PRINTER ASSEMBLY	17	3PB4083-6030P001	REGISTRATION ROLLER	1	*	*	*			
PRINTER ASSEMBLY	19	42037001	Roller Assy.-TR_F	1	*	*	*			G
PRINTER ASSEMBLY	20	3PB4083-6064P002	BACK-UP ROLLER	1	*	*	*			G
PRINTER ASSEMBLY	21	4PP4083-6052P001	BUSH A	2	*	*	*			
PRINTER ASSEMBLY	22	4PP4083-6065P001	BIAS SPRING A	2	*	*	*			
PRINTER ASSEMBLY	23	1PP4083-6035G001	LOWER BASE SUBASSEMBLY	1	*	*	*			G
PRINTER ASSEMBLY	24	3PP4083-6058P001	SWITCH ARM LEVER	1	*	*	*			
PRINTER ASSEMBLY	25	3PP4083-6053P001	RESET LEVER L	1	*	*	*			
PRINTER ASSEMBLY	26	4PP4083-6057P001	RESET SPRING	1	*	*	*			
PRINTER ASSEMBLY	27	4PB4083-6197P001	DAMPER FRAME	1	*	*	*			
PRINTER ASSEMBLY	28	4PP4083-6191G001	DAMPER ARM ASSEMBLY	1	*	*	*			G
PRINTER ASSEMBLY	29	4PA4083-6025G001	EJECT SENSOR LEVER ASSEMBLY	1	*	*	*			
PRINTER ASSEMBLY	30	2PA4120-1129G001	EJECT ROLLER ASSEMBLY F	1	*	*	*			
PRINTER ASSEMBLY	31	2PA4120-1085G001	RELEASE GUIDE ASSEMBLY	1	*	*	*			
PRINTER ASSEMBLY	32	4PP4120-1087P001	RELEASE SPRING	1	*	*	*			
PRINTER ASSEMBLY	33	4YA4116-1228G001	LED HEAD GENERAL SPEC. 31B	1	*	*	*			G
PRINTER ASSEMBLY	34	2241022P0140	FV03-S14-S1-201-11	1	*	*	*			
PRINTER ASSEMBLY	35	42480701	Cable Assy.-LED_Head	1	*	*	*			X
PRINTER ASSEMBLY	42	40778901	SENSOR WIRE ASSEMBLY	1	*	*	*			
PRINTER ASSEMBLY	45	3PP4083-6071G001	MOTOR PLATE ASSEMBLY	1	*	*	*			G
PRINTER ASSEMBLY	46a	3PB4120-1105P001	HALOGEN LAMP(Q)-F120	1	*	*	*			
PRINTER ASSEMBLY	46b	3PB4120-1105P002	HALOGEN LAMP(Q)-F230	1	*	*	*			

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environmen
					per *	per *	per *			
PRINTER ASSEMBLY	47	4PB4083-6106P001	HEAT SENSOR	1	*	*	*			G
PRINTER ASSEMBLY	48	4PB4083-6293P001	THERMOSTAT A	1	*	*	*			G
PRINTER ASSEMBLY	49	4PB4083-6128P001	BEARING B	2	*	*	*			
PRINTER ASSEMBLY	50	4PP4083-6113P001	GEAR A	1	*	*	*			
PRINTER ASSEMBLY	51	4PP4083-6031P001	BEARING R	1	*	*	*			
PRINTER ASSEMBLY	52	40559101	Spring-Compression R(I/D)	2	*	*	*			
BASE ASSEMBLY	1b	41067001	PWR unit-ACDC Switch	1	*	*	*	(230V) Except ODA		G
BASE ASSEMBLY	2	3PA4083-6090G001	CONTACT ASSEMBLY	1	*	*	*			
BASE ASSEMBLY	3	43333501	Board- HF8	1	*	*	*			
BASE ASSEMBLY	4a	42341801	PCB UnitV60	1	*	*	*	Except TAIWAN		G
BASE ASSEMBLY	5	2YX4076-7012G001	CASSETTE GUIDE R ASSEMBLY	1	*	*	*			G
BASE ASSEMBLY	6	3PP4083-7653P001	CASSETTE LOCK LEVER	2	*	*	*			
BASE ASSEMBLY	7	4PP4083-7655P001	CASSETTE LOCK SPRING	2	*	*	*			
BASE ASSEMBLY	8	4PP4122-1170P001	LINK PULL LEVER	2	*	*	*			
BASE ASSEMBLY	9	4PP4083-7666P001	SHEET SPRING	2	*	*	*			
BASE ASSEMBLY	10	4PP4083-7658G001	SHEET LINK R ASSEMBLY	1	*	*	*			G
BASE ASSEMBLY	11	1PA4120-1162G001	PAPER CASSETTE ASSEMBLY	1	*	*	*			G
BASE ASSEMBLY	12	40259701	Frame Assy.-Sepa.	1	*	*	*			
BASE ASSEMBLY	13	3PP4083-7660P001	BEAM PLATE	2	*	*	*			G
BASE ASSEMBLY	14	2PA4076-7011G001	CASSETTE GUIDE L ASSEMBLY	1	*	*	*			G
BASE ASSEMBLY	15	1PP4120-1078P001	BASE PLATE	1	*	*	*			G
BASE ASSEMBLY	16	3PP4083-6154P001	CASSETTE DETECTION LEVER	1	*	*	*			
BASE ASSEMBLY	17	4PP4083-7667P001	PAPER END SENSOR LEVER	1	*	*	*			
BASE ASSEMBLY	18	41358601	Sheet-Insulation	1	*	*	*			
BASE ASSEMBLY	19	41348401	Motor-Fan_DC	1	*	*	*			G
BASE ASSEMBLY	25	4PP4083-7657G001	SHEET LINK L ASSEMBLY	1	*	*	*			G
BASE ASSEMBLY	26	4PP4083-7662P001	FG PLATE C	1	*	*	*			
BASE ASSEMBLY	32	42353404	Card-ICP	1	*	*	*			X
BASE ASSEMBLY	33	4PP4083-7665P001	FG PLATE D	1	*	*	*			
BASE ASSEMBLY	37	40071701	Holder-PCIF(B)	1	*	*	*			G
BASE ASSEMBLY	38	42282501	Plate-Shield(FG)	1	*	*	*			
BASE ASSEMBLY	41	41319501	Bracket-Support_PSU	2	*	*	*			G
BASE ASSEMBLY	42	41076201	Spacer-Rubber_PSU	1	*	*	*	Except ODA,For the unit produced from July 2004.		
SCAN UNIT	1	1PP4120-1015P001	SCANNER FRAME	1	*	*	*			
SCAN UNIT	2	2PP4120-1034P001	SCANNER BASE FRAME L	1	*	*	*			G
SCAN UNIT	3	4PP4120-1023P001	EARTH PLATE ADF	1	*	*	*			
SCAN UNIT	4	3PP4120-1017P001	PC2 LEVER	1	*	*	*			
SCAN UNIT	5	3PP4120-1016P001	PC1 LEVER	1	*	*	*			
SCAN UNIT	6	3PP4120-1038P001	POCKET PLATE	1	*	*	*			G
SCAN UNIT	7	2PP4120-1037P001	SCANNER BASE FRAME R	1	*	*	*			G
SCAN UNIT	8	4PP4120-1032P001	LATCH SPRING	2	*	*	*			
SCAN UNIT	9	4PP3529-5045P001	PINCH ROLLER	1	*	*	*			
SCAN UNIT	10	4PP4120-1020P001	PINCH ROLLER SHAFT	1	*	*	*			
SCAN UNIT	11	4PP4120-1022P001	PINCH SPRING R	1	*	*	*			
SCAN UNIT	12	4PP4120-1021P001	PINCH SPRING L	1	*	*	*			
SCAN UNIT	13	4PP3529-5033P001	GEAR(Z20)	1	*	*	*			
SCAN UNIT	14	4PA3529-5082G001	SUB-ROLLER ASSEMBLY	1	*	*	*			G
SCAN UNIT	15	2PP4120-1029P001	SCANNER BOTTOM PLATE	1	*	*	*			G
SCAN UNIT	16	4PP3529-5039P001	GEAR(Z81/15)	1	*	*	*			
SCAN UNIT	17	4PB3527-5803P001	MINI CLAMP HOLDER	4	*	*	*			
SCAN UNIT	18	40135301	Photo-Interrupter	2	*	*	*			G
SCAN UNIT	19	4PP4120-1030P001	SENSOR SPRING	1	*	*	*			
SCAN UNIT	20	40141401	Contact Image Sensor	1	*	*	*	300DPI		G
SCAN UNIT	21	3PA4120-1018G001	ADF ROLLER ASSEMBLY	1	*	*	*			G
SCAN UNIT	22	40047601	Motor-S(FX-VP)	1	*	*	*			G
SCAN UNIT	24	4PB4120-1024P001	EJECT PINCH ROLLER	1	*	*	*			
SCAN UNIT	25	4PP4120-1025P001	EJECT PINCH SPRING	2	*	*	*			
PAPER GUIDE U ASSEMBLY	1	3PA4120-1045G001	FEED ROLLER(1)ASSEMBLY	1	*	*	*			G
PAPER GUIDE U ASSEMBLY	2	4PP4120-1226P001	Earth-Plate(SR)	1	*	*	*			
PAPER GUIDE U ASSEMBLY	3	4PP4120-1227P001	Earth-Plate(SL)	1	*	*	*			

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environmen
					per *	per *	per *			
PAPER GUIDE U ASSEMBLY	4	4YS4011-1714P002	EARTH CORD	1	*	*	*			
PAPER GUIDE U ASSEMBLY	5	1PP4120-1040P001	PAPER GUIDE U	1	*	*	*			
PAPER GUIDE U ASSEMBLY	6	4PA4120-1041G001	PINCH PLATE ASSEMBLY	1	*	*	*			
PAPER GUIDE U ASSEMBLY	7	4PB4120-1051P001	DISELECTRIFICATION BRUSH	1	*	*	*			G
PAPER GUIDE U ASSEMBLY	8	4PP3529-5035P001	GEAR(Z28)	1	*	*	*			
PAPER GUIDE U ASSEMBLY	9	4PA3529-5087G001	SEPARATION RUBBER ASSEMBLY	1	*	*	*			
PAPER GUIDE U ASSEMBLY	10	3PA4120-1049G001	SENSOR ROLLER ASSEMBLY	1	*	*	*			G
PAPER GUIDE U ASSEMBLY	11	4PP3529-5034P001	GEAR(Z22)	1	*	*	*			
PAPER GUIDE U ASSEMBLY	12	3PA4120-1052G001	EXIT ROLLER ASSEMBLY	1	*	*	*			
PAPER GUIDE U ASSEMBLY	13	4PP3527-5153P001	BACK-UP PLATE	1	*	*	*			
PAPER GUIDE U ASSEMBLY	14	4PP4120-1044P001	ADF SPRING	1	*	*	*			
PAPER GUIDE U ASSEMBLY	15	4PB4120-1051P002	DISELECTRIFICATION BRUSH	2	*	*	*			
PAPER GUIDE U ASSEMBLY	16	4PP3522-3568P001	BEARING ADF	2	*	*	*			
PAPER GUIDE U ASSEMBLY	18	4YS4011-1714P003	EARTH CORD	1	*	*	*			G
PAPER GUIDE U ASSEMBLY	19	4PP3527-5034P001	GEAR(Z16)	2	*	*	*			
PAPER GUIDE U ASSEMBLY	20	4PB4013-3501P003	CS-RING(CS4-SUS)	2	*	*	*			
CABLES	1	40040002	CONN Cord-Wire(OPE)	1	*	*	*			G
CABLES	2	4YB4120-1026P001	SPEAKER	1	*	*	*			G
CABLES	3	3YS4111-3527P002	CONNECTOR CORD	1	*	*	*			G
CABLES	4	4YS4111-3441P001	CONNECTOR CORD(CIS)	1	*	*	*	(CIS)		G
CABLES	5	4YS4111-3442P001	CONNECTOR CORD(PC1/2)	1	*	*	*	(PC1/2)		G
CABLES	6	1051070C0001	TFC-16813	2	*	*	*	(FAN/Speaker)		G
CABLES	7c	236A6058P0001	4622-007-0092	1	*	*	*	OEL, Note 4		G
CABLES	10	105A1051C3002	TR-28-16-20	1	*	*	*	(2nd Tray Cable)		G
CABLES	15	105A1070C0004	TFC-23-11-14	1	*	*	*	(OPE Cable)		G
CABLES	16	105A1070C0003	TFC-20-10-10	1	*	*	*	(Sensor Cable)		G
CABLES	17	4YB4120-1094P001	SECONDARY BATTERY	1	*	*	*			G
CABLES	18	LP-1466	SNAP BAND	*	*	*	*			
CABLES	19	LP-6401-B1	TYING CORD	1	*	*	*			
CABLES	22	40808001	CONN Cord-PSU(High/Low)	1	*	*	*			G
Paper Feeder	1	1PP4122-1401P001	Upper Plate	1	*	*	*			G
Paper Feeder	2	3PA4122-1370G001	Sheet guide assembly	1	*	*	*			
Paper Feeder	3	1PA4122-1369G001	Front cover assembly	1	*	*	*			G
Paper Feeder	4	3PA4122-1371G001	Inner guide assembly	1	*	*	*			
Paper Feeder	5	1PA4122-1362G004	Cassette assembly	1	*	*	*			G
Paper Feeder	6	4PA4120-1009G001	Separation frame assembly	1	*	*	*			
Paper Feeder	7	1PP4122-1323P001	Rear Cover	1	*	*	*			
Paper Feeder	8	4PB4122-1441P001	Stick finger	1	*	*	*			
Paper Feeder	9	1PA4122-1366G001	Hopping flame assembly	1	*	*	*			G
Paper Feeder	10	4PP3522-3568P001	BEARING ADF	1	*	*	*			
Paper Feeder	11	4PP4122-1207P001	Gear (Z70)	1	*	*	*			
Paper Feeder	12	3PP4122-1331P001	Lever sensor (P)	1	*	*	*			
Paper Feeder	13	3PA4122-1393G001	Feed roller assembly	1	*	*	*			
Paper Feeder	14	3YS4111-3528P001	Connector cable	1	*	*	*			
Paper Feeder	15	3PB4122-1399P001	Stepping motor	1	*	*	*			G
Paper Feeder	16	4PP4122-1384G001	Bracket	1	*	*	*			G
Paper Feeder	17	4PP4122-1383P001	Gear (Z24)	2	*	*	*			
Paper Feeder	18	4PP4122-1226P001	Gear (Z87/Z60)	1	*	*	*			
Paper Feeder	19	2PP4122-1389P001	Plate-Bottom	1	*	*	*			G
Paper Feeder	20	1PA4122-1365G001	2nd cassette guide (L) assy	1	*	*	*			G
Paper Feeder	21	3PA4122-1367G001	Hopping roller assembly	1	*	*	*			

Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environmen
					per *	per *	per *			
Paper Feeder	22	1YX4122-1364G002	Second Guide (R) Assy	1	*	*	*			G
Paper Feeder	23	4PB4122-1382P001	One-way gear (Z32)	1	*	*	*			
Paper Feeder	24	42372702	Board-GRT	1	*	*	*			G
Paper Feeder	25	3PA4122-1372G001	Tail Guide Assy	1	*	*	*			
Paper Feeder	26	4PP4122-1238P002	Separation Spring	1	*	*	*			
Paper Feeder	27	4PP4122-1184P001	Lever Cassette Lock	1	*	*	*			
Paper Feeder	28	4PP4122-1347P001	Lock Spring	1	*	*	*			
Paper Feeder	29	4PP4122-1217P001	Link-Pull_Lever	1	*	*	*			
Paper Feeder	30	4PP4122-1398P002	Sheet Spring	1	*	*	*			
Paper Feeder	31	4PP4122-1339G001	Sheet Link (L)	1	*	*	*			G
Paper Feeder	32	4PP4122-1338G001	Sheet Link (R)	1	*	*	*			G